



Synology PSU



1- Connect the special Synology Adaptor (12 and 8 pin connectors) to 2 Molex and 1 SATA PSU connectors:



2- The rear bracket must be turned over and passed between the cables as illustrated below.



3- Some Synology boxes are wide and require a 24pin extension for the cable to run from one side all the way to the side of the box. There may be limited room under the lid to accommodate the extension so it may be necessary to cut off the small retention clip on the PSU 24pin connector. This should allow the lid to close properly. See illustration below:

